

# BKHC0# Brake Kit Installation

Hydraulic Brakes Installation.



**Hydraulic Brakes** 1 Piece assembled (Master, 2x Lines, Calliper). \*RECOMMENDED FIT KIT Contains: 3x Zip Ties, 2x M8x50mm Square Head bolts, 2x M8 Nylocs, 2x M8x20mm Square Hex Socket Head bolts, 2x M8 8mm Spacers, 2x M8 Washers

- a. Fit the calliper to the vertical rear calliper bracket on the left side of the kart beside the outer bearing axle bracket. Slide the calliper over the disc.
- b. Adjust the disc by loosening the hub locking bolts and sliding the disc sideways until it is central within the calliper.
- c. Tighten the hub locking nuts.
- d. Using the two M8x20mm bolts, push each bolt through the bracket, then through an M8 8mm spacer, then through an M8 washer and screw into the calliper (see below). Tighten.



- e. Run the master through the opening between the seat brackets and the chassis rail.
- f. Fix the master to the outer side of the bracket beside the seat using the two M8x50mm Square head bolts.
- g. Push the bolts through the master from the outside, then through the master bracket, then secure using the two M8 Nyloc nuts. Tighten.



- h. Fix the line to the seat uprights with the three zip ties provided.

