

# PEDC01 Pedal Set

## Pedals Installation



**Pedals 2 Pieces** \*FIT KIT = Pedal Kit Contains: 2x M8x70 Hex Head bolts with sleeves, 2x M8 Nylocs. Recommended for install: 2x Springs (SPPRHD), 1x Retainer Pin & Split Pin PNBK1

Fit the brake Pedal (has a square plate bracket at the rear) the left side of the kart by inserting the M8 bolt through one or both sleeves and then the pedal, then through the sleeve bracket at the front of the kart (just in front of the large front chassis rail). Secure with M8 nyloc.

Connect your brake rod to the pedal bracket with a pin and split pin (see brake rod installation) or if your brake lever is operated by a cable (or your brakes are a cable system) attach the cable through the hole where the pin would usually be connected.

Fit a pedal return spring to the loop on the frame, then to the loop of the rear of the pedal.

Fit the throttle pedal on the right side of the kart by inserting the M8 bolt through one or both sleeves and then the pedal, then through the sleeve bracket at the front of the kart (just in front of the large front chassis rail). Secure with M8 nyloc.

Fit the pedal return spring to the loop on the frame, then to the loop of the rear of the pedal.