

BKCVC1 Brake Disc Guard

Brake Disc Guard Installation.



Brake Guard 1 piece *FIT KIT NOT SUPPLIED – No extra fitting bolts are required if your chassis has an axle already installed. Suits 78mm hole centre to hole centre bearing holders.

- a. Remove the M8x50 bolt at the top front of the left side bearing and the M8x50 bolt at the top rear of the left side bearing.
- b. Place the Brake Guard in position over the brake with the bracket holes lining up on the outside of the left side bearing bracket.
- c. Re-install the two M8x50 bolts.